## Wheelchair Propulsion Test (WPT)® Version 1.0 Form

Subject #: Two- hand example. Date: Dec 6, 2012. Time: 11:00 am Test # 1

Decorded Detex	
Recorded Data*  1. Able to successfully complete the 10m distance?  Yes ☑ No ☐	
2. Direction of travel	Forward Backward
3. Limbs contributing to propulsion, steering or braking (tick all that	Left: Hand 🗷 Leg 🗆
apply)	Right: Hand 🖾 Leg 🗆
	Right: Hand 🖴 Leg 🗀
4. Limb monitored for timing propulsion cycles (tick one limb)	Left: Hand □ Leg □
<b>3</b>	Right: Hand ☑ Leg □
5. Time (to nearest second)	
Time (to nome second)	_/O_s
6. Total number of propulsive cycles (to nearest full cycle)	
	cycles
7. If using one or more hands for propulsion in the forward	Yes□ No 🖾
direction, during the <i>contact phases</i> , did the subject generally	Not applicable □
begin the contact between the hands and the hand-rims behind the	
top dead center of the rear wheel?	
8. If using one or more hands for propulsion in the forward	Yes □ No 🗹
direction, during the recovery phases, did the subject generally	Not applicable □
use a path of the hands that was predominantly beneath the hand-	
rims?	
9. If using one or more <i>feet for propulsion</i> and going forward, did the subject make initial foot contact with the knee flexed less than	Yes No D
90° from full extension and finish with the knee flexed more than	Not applicable
90° (or the opposite if going backward)?	
10. Comments: (e.g., position on seat, trunk and arm posture, hand grip, foot contact, consistency,	
need for training, footwear, equipment worn, wheelchair issues)	
#7 - Hands near top dead center, but not consistently behind.	
the A	
#8 - Arc recovery pattern	
Derived Wheelchair-Propulsion Data*	
1. Speed: 10m / <u>/o</u> # seconds =	
1. Speed. Tolli / # secolds =	<u> </u>
2. Push frequency (cadence)://_ # cycles //o # seconds =	_/./_ cycles/s
	<b>J</b> • • • • • • • • • • • • • • • • • • •
3. Effectiveness: 10m /# cycles =	m/cycle
*Directions on next page.	
Tostor signatures SA Tostor name (swint)	
Tester signature: Tester name (print):	